



SWITCH

Mobile Markerboard



ASSEMBLY INSTRUCTIONS

Hardware Included

4 - ¼" - 20 x 1 ½" cap head bolts

Tools Needed

3/16" Allen wrench

Instructions

1. Remove the unit from the carton and inspect.
2. Lay the unit on a flat surface.
3. Open the box with the legs and inspect.
4. Using the 4 - ¼" - 20 x 1 ½" bolts attach foot block and legs to the unit by sliding the foot block in to the slot at the bottom of the unit, insert bolts and tighten. Please note that the feet on each side to be facing the same direction in order for the units to nest correctly, i.e., left feet both facing down and right feet both facing up.



800-434-4610
calyxbyclaridge.com

WARNING
Risk of injury to installers and users
Read the entire assembly directions before
beginning assembly.