

VENUE Mobile Markerboard



ASSEMBLY INSTRUCTIONS

Hardware Included

- 1. 2 each 3/8-16" x 3"
- 2. Tools Needed
- 3. Allen wrench 5/16"
- 4.

Instructions

- 1. Lay unit on flat surface and ensure all pieces are accounted for
- 2. Slide foot onto mounting block and secure using 3/8-16" x 3" bolts (included) to secure foot to unit.
- 3. After foot is secured attach caster by compressing, caster is secure when it locks into place. Stand unit up.

